



1. Cut on red line to separate four pallets. Don't cut out the pallets just yet !
2. Make a series of sharp folds on the 8 edges and tabs shown here:
3. Cut out each pallet using an Exacto knife.
4. Fold the pallet. The four tabs marked "2" go on the bottom.
5. Put a dab of white glue on the last #2 tab to hold it together.

Compliments of the
Yosemite Portland Cement Co.